WARNING FLOOR JACK

Any piece of equipment can be dangerous if not operated properly. <u>YOU</u> are responsible for the safe operation of this equipment. The operator must carefully read and follow any warnings, safety signs and instructions provided with or located on the equipment. Do not remove, defeat, deface or render inoperable any of the safety devices or warnings on this equipment. If any safety devices or warnings have been removed, defeated, defaced, or rendered inoperable, <u>DO NOT USE THIS EQUIPMENT!!!</u>

WARNING: This product can expose you to chemicals including naphthalene and benzene from petroleum products which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to <u>www.P65warnings.ca.gov</u>

DANGER: THIS EQUIPMENT HAS MULTIPLE PINCH POINTS THAT CAN CAUSE DISMEMBERMENT OR DEATH! KEEP HANDS, FEET AND ALL OTHER BODY PARTS CLEAR AT ALL TIMES.

IMPORTANT SAFETY RULES TO FOLLOW

- Know where to place the jack. **Before** jacking up the vehicle, check the owner's manual for information on where to place the jack.
- **Before** jacking up the vehicle, place chocks in front of and behind the wheels, to prevent it from rolling.
- Always use the jack on a solid, hard surface that is level to prevent rolling.
- After jacking up the vehicle. **Always** place safety stands in the places recommended in the owner's manual.
- If the jack is being used for other lifting purposes, support raised loads with the appropriate supports never use the jack as the sole means of support.
- **NEVER** get under or place any body parts under a vehicle, or anything else, that is held up solely by the jack.
- Do not allow load to cock on jack, as jack may kick out causing injury to the operator or the load to fall.
- Keep all body parts including arms, legs, fingers, & toes clear of lifted loads at all times.
- Do not exceed the jack's capacity & when using more than one jack to lift a load, each jack must have the lifting capacity of the entire load being lifted.
- Keep lifted loads as low as possible.

WARNING

Slowly turn the release valve. Turning the release valve quickly makes the load fall rapidly and may lead to the loss of the load or damage to the jack! Failure to comply may cause serious injury and/or property damage!

If the person receiving this handout will not be the user of the equipment, forward these instructions to the operator. If there is any doubt as to the operation or safety of the equipment, <u>DO NOT USE!!! CALL A TOOL SHED IMMEDIATELY!!!</u> FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN INJURY OR DEATH