


WARNING SCREW JACK SAFETY

Any piece of equipment can be dangerous if not operated properly. **YOU** are responsible for the safe operation of this equipment. The operator must carefully read and follow any warnings, safety signs and instructions provided with or located on the equipment. Do not remove, defeat, deface or render inoperable any of the safety devices or warnings on this equipment. If any safety devices or warnings have been removed, defeated, defaced, or rendered inoperable, **DO NOT USE THIS EQUIPMENT!!!**

 **WARNING:** This product can expose you to chemicals including Chromium from steel products, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65warnings.ca.gov

DANGER SCREW JACKS ARE NOT FOR VEHICLE USE

Danger: Never strike the jack with any foreign object. Always lower the jack to reposition.

This jack has and creates Multiple Pinch Points. If used incorrectly it may kick out with Extreme Force. This could cause serious injury or death to the operator or bystanders. Keep hands, feet and all other body parts clear at all times.

WARNING: IMPORTANT SAFETY RULES TO FOLLOW

- Do not lift more than the rated capacity of the jack.
- Use the jack on flat, level, and hard surfaces only. Never use a jack on a slope or soft surfaces.
- Always center jack under load
- Do not allow load to “tilt” on jack, as the jack may kick out causing injury to the operator and, or load to fall.
- When using more than one jack to lift a load, each jack must have the lifting capacity of the entire load being lifted.
- Keep all body parts including arms, legs, fingers, and toes clear of lifted load at all times.
- Never force screw past its safety stop.
- Remove the handle from the jack when not in use.

OPERATION:

1. Select a screw jack with the proper lifting capacity.
2. Place on a flat, hard surface beneath the load to be lifted.
3. Use your hand to turn the screw out until it contacts the surface to be lifted.
4. Insert a steel turning bar through one of the two cross holes under the lifting pad.
5. Rotate the turning bar counter-clockwise until desired height is reached.

WARNING

Screw Jacks are provided with a safety stop to prevent the screw from coming all the way out when the stop is reached. **DO NOT** force the screw. Never force the screw past the safety stop! Failure to comply may cause serious injury or death, and/or damage to property and the jack.

If the person receiving this handout will not be the user of the equipment, forward these instructions to the operator. If there is any doubt as to the operation or safety of the equipment, **DO NOT USE!!! CALL A TOOL SHED IMMEDIATELY!!! FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN INJURY OR DEATH**